# PRO-GREEN IRRIGATION MEDIUM BODIED LOW VOC PVC CEMENT IR-SPEC

## **PRODUCT DESCRIPTION**

## PRODUCT

**PRO-GREEN** Irrigation Medium Bodied Low VOC PVC Cement

#### <u>TYPE</u>

**PRO-GREEN** is a fast one step cement for use through 6" (15.24 cm) diameter on all classes of PVC pressure pipe and 8" (20.32 cm) diameter on non-pressure PVC pipe where pipe pulling is required and conditions are wet and/or quick pressurization is needed. Specifically formulated for the irrigation and sprinkler contractor.

Recommended as a One-Step Solvent Weld Cement for Drain, Waste and Vent (DWV) pipe and fittings in non-pressure applications in sizes up to 4" (10.16 cm) where acceptable by local code.

COLOR/CONSISTENCY Green / Medium Bodied

TEMPERATURE RANGE USE 0°F (-17°C) to 120°F (49°C)

# PRESSURE RANGE USE

Liquids: Up to 300 PSI (2068 kPa)

#### **DRYING TIME**

Partial set time rating: Fast - approximately 20 seconds. Complete cure time is 24 hours.

#### **U.S. FEDERAL SPECIFICATIONS**

**PRO-GREEN** meets ASTM D2564 and ASTM F3328-18.

Carries the National Sanitation Foundation Seal for Potable Water and Drain, Waste and Vent (DWV) and Sewer Waste (SW) systems.



IR-SPEC
© 2025 J.C. Whitlam Manufacturing Company
This product is manufactured in the U.S.A.

### APPLICATION PRECAUTIONS

WARNING: EXTREMELY FLAMMABLE. DO NOT USE NEAR HEAT, SPARKS OR OPEN FLAME. STORE IN COOL, WELL VENTILATED AREA.

CONTAINS TETRAHYDROFURAN, CYCLOHEXANONE AND METHYL ETHYL KETONE. MAY BE ABSORBED THROUGH THE SKIN. HARMFUL OR FATAL IF SWALLOWED.

USE WITH ADEQUATE VENTILATION. AVOID PROLONGED BREATHING OF VAPORS. AVOID CONTACT WITH EYES OR SKIN. KEEP CONTAINER TIGHTLY CAPPED WHEN NOT IN USE.

KEEP OUT OF REACH OF CHILDREN.

SEE SAFETY DATA SHEET (SDS) FOR COMPLETE PRECAUTIONS FOR SAFE HANDLING AND USE.

#### **ENVIRONMENTAL STATEMENT**

This product emits less than 425 grams per liter VOC when tested according to SCAQMD method 316 A.

WARNING: This product can expose you to chemicals including N-methylpyrrolidone, which is known to the State of California to cause birth defects or other reproductive harm. For more information, go to

## www.P65Warnings.ca.gov

## PACKAGING

Stock Code	<u>Size</u>			
Dauber Top Can				
IR4	¼ pint (118 ml)			
IR8	1/2 pint (237 ml)			
IR16	1 pint (473 ml)			
IR32	1 quart (.95 L)			
1 Gallon Can w/ Handle				
IR1	1 gal. (3.785 L)			

#### WEIGHT PER U.S. GALLON

7.89 lbs. (3.58 kg) ± 0.2

#### SHIPPING WEIGHT PER CASE

Stock		
<u>Code</u>	Case Weight	#/Case
IR4	10 lbs. (4.5 kg)	24
IR8	16 lbs. (7.3 kg)	24
IR8A	9 lbs. (4.1 kg)	12
(Display		
IR16	15 lbs. (6.8 kg)	12
IR32	28 lbs. (12.7 kg)	12
IR1	56 lbs. (25.4 kg)	6

# **DIRECTIONS FOR USE**

1. Cut the pipe square and remove all burrs.

2. Check fitting of pipe. If it is too loose or too tight, pipe should not be used. The ideal fit between pipe and fitting before cementing allows pipe to enter to full depth of socket easily.

3. Remove all dust, moisture, grease, oil and any other foreign material from pipe and fitting. Clean pipe and fitting with **TALON Low VOC Purple Primer**. While surface is still damp with primer, apply cement as follows.

4. Apply enough **PRO-GREEN** uniformly to pipe and fitting to form a bead of cement at outside end of pipe. Prevent excess cement from forming on bare inside walls of pipe.

5. Brush **PRO-GREEN** generously on the outside of the pipe to the depth of the fitting. Do not thin cement with primers or cleaners.

6. Immediately after **PRO-GREEN** is applied, insert pipe to the bottom of the socket, using a quarter twisting motion, and hold in place 30 seconds until **PRO-GREEN** sets. Assemble parts QUICKLY. If cement is not fluid, re-coat both parts and repeat procedure.

7. Remove excessive **PRO-GREEN** with a dry cloth only.

8. Allow about 30 minutes for good handling strength. Allow 4 hours for high strength. For best quality joints, remove water or moisture from pipe and fitting and allow 2-24 hours cure time. Cure time before testing depends on size, fit, temperature and pressures. Refer to ASTM Spec. D2855, for recommended set and cure time.

9. Keep container closed at all times when not using to avoid moisture absorption and vapor losses. Keep cement from freezing.

10. Special green dye allows you to see application.

11. Follow all recommended procedures for joining PVC pipe and fittings as stated in ASTM Spec. 2855.



Website: www.progreenglue.com

The information contained in this bulletin is correct to the best of our knowledge. The recommendations or suggestions herein are made without guarantee or representation as to result, since the conditions of use are beyond our control. We suggest that you evaluate the recommendations contained in this bulletin. No statement is to be construed as violating any copyright or patent. They are intended only as a source of information. \*Note: Both set time and cure time are affected by humidity and temperature and may vary greatly ±.