

FREEZE-POINT -100

-100°F (-73°C) BURST PROTECTION

FP-SPEC

PRODUCT DESCRIPTION

PRODUCT

FREEZE-POINT -100 Anti-Freeze and Heat Transfer Fluid for HVAC, Potable Water, and Solar Systems.

TYPE

Nontoxic Propylene Glycol Anti-Freeze with special anti-corrosion inhibitors, color indicators and burst protection to -100°F (-73°C).

RECOMMENDED USES

FREEZE-POINT -100 is ideal for water based systems requiring maximum freeze and corrosion protection without the risk of environmental contamination.

FREEZE-POINT -100 works excellent in:

- Closed Loop Solar Systems
- Hydronic HVAC Systems
- Potable Water Lines
- Sprinkler Systems
- Irrigation Lines
- Recreational Vehicles
- Pleasure Craft

FREEZE-POINT -100 Anti-Freeze is an economical pre-blend to allow for direct replacement of water in the system with equal amounts of **FREEZE-POINT-100** Anti-Freeze for burst protection down to -100°F (-73°C). The direct replacement of water with anti-freeze, without having to measure or calculate the amount of anti-freeze needed, provides for an error free method to protect the system. **FREEZE-POINT -100** Anti-Freeze can also be diluted to offer higher freeze points and burst protection in warmer climates (see freeze and burst protection chart).

FREEZE-POINT -100 Anti-Freeze lubricates pumps, valves and moving parts. **FREEZE-POINT -100** Anti-Freeze will not harm plastic or rubber seals, o-rings, or gaskets.

FP-SPEC

© 2005 J.C. Whitlam Manufacturing Company
This product is manufactured in the U.S.A.

RECOMMENDED USES CONTINUED

FREEZE-POINT -100 Anti-Freeze is suitable for use with continuous operating systems with temperatures up to 250°F (107°C), and will not degrade significantly from short term exposures to temperatures up to 350°F (162°C).

COLOR/CONSISTENCY

Blue Liquid

ENVIRONMENTAL STATEMENT

FREEZE-POINT -100 Anti-Freeze is nontoxic, nonflammable, and noncorrosive. **FREEZE-POINT -100** Anti-Freeze eliminates the possibility of contaminating domestic and potable water systems. **FREEZE-POINT -100** Anti-Freeze will not support bacterial growth.

APPLICATION PRECAUTIONS

FREEZE-POINT -100 Anti-Freeze has a greater tendency to leak past faulty joints than water, so all leaks must be corrected properly.

LIMITATIONS

Do not use in systems containing galvanized pipe or aluminum. Do not use in conjunction with boiler treatment chemicals without first consulting the manufacturer.

PACKAGING

U.S. Measure:

Stock Code	Size
FP1	1 gal. (3.78 L)
FP5	5 gal. (18.9 L)
FP55	55 gal. (208 L)

WEIGHT PER U.S. GALLON

8.57 lbs. (3.9 kg) ± 0.2

SHIPPING WEIGHT PER CASE

Stock#	Case Weight	#/Case
FP1	54 lbs. (24.5 kg)	6/case
FP5	45 lbs. (20.4 kg)	1/case
FP55	515 lbs.(233.6 kg)	1/case

DIRECTIONS FOR USE

1. Empty the entire system through faucets, petcocks, and other openings. Then close all openings.
2. Replace all water in the system with an equal amount of **FREEZE-POINT -100** Anti-Freeze to obtain -100°F (-73°C) burst protection. When using **FREEZE-POINT -100** Anti-Freeze to make less concentrated mixtures, use the Freeze and Burst Protection Chart to determine the correct dilution ratio to obtain the desired burst and freeze protection. Do not make mixtures less concentrated than shown on the table.
3. Be sure to protect all drains by adding **FREEZE-POINT -100** Anti-Freeze to traps and toilets to prevent freezing. Open each faucet to be sure **FREEZE-POINT -100** Anti-Freeze has displaced any water pockets. Close faucets when the blue color of **FREEZE-POINT -100** Anti-Freeze appears.
4. For circulating hot water heating systems and solar heating and cooling systems, **FREEZE-POINT -100** Anti-Freeze can remain in the system all year. Be sure to flush the system thoroughly of dirt, scale or oil prior to adding **FREEZE-POINT -100** Anti-Freeze.
5. Test the entire system for freeze protection and acid corrosion protection with **FREEZE-POINT -100** Test Strips. Additional **FREEZE-POINT -100** Anti-Freeze may be required. Test the system annually.

(over)



Division of
J.C. Whitlam Mfg. Company
P.O. Box 380
Wadsworth, Ohio 44282
Phone: 330-334-2524
Fax: 330-334-3005
email: info@jcwhitlam.com
website: www.jcwhitlam.com

FREEZE-POINT -100

-100°F (-73°C) BURST PROTECTION

FP-SPEC


**NON-TOXIC
ANTI-FREEZE
PROTECTS SYSTEMS TO
-100°F (-73°C)**

TECHNICAL CHARACTERISTICS

FREEZE POINT -100 FREEZE AND BURST PROTECTION CHART				
FREEZE PROTECTION	BURST PROTECTION	CONCENTRATION	PARTS BY VOLUME FREEZE POINT -100 CONCENTRATE	PARTS BY VOLUME WATER
0°F (-17°C)	-50°F (-46°C)	50%	1	1
-5°F (-21°C)	-54°F (-48°C)	60%	3	2
-15°F (-26°C)	-59°F (-51°C)	75%	3	1
-35°F (-37°C)	-80°F (-62°C)	80%	4	1
-50°F (-46°C)	-100°F (-73°C)	100%	UNDILUTED	0

HOW TO SIZE YOUR SYSTEM

The capacity of your boiler can be found on the boiler plate, in the boiler manual or contact the manufacturer. Use the following chart to help determine the number of gallons of **FREEZE POINT** mixture required to fill the system.

VOLUME/PIPE SIZING									
	PIPE DIAMETER								
	½"	¾"	1"	1½"	2"	2 ½"	3"	3 ½"	4"
Number of Gallons Per 100' Standard Steel Pipe	1.6	2.8	4.5	10.5	17.5	25.0	39.0	53.0	66.7
Number of Gallons Per 100' Type "L" Copper Tubing	1.2	2.5	4.3	9.3	16.1	24.8	35.4	47.8	62.0

FP-SPEC

© 2005 J.C. Whitlam Manufacturing Company
This product is manufactured in the U.S.A.



Division of
J.C. Whitlam Mfg. Company
P.O. Box 380
Wadsworth, Ohio 44282
Phone: 330-334-2524
Fax: 330-334-3005
email: info@jcwhitlam.com
website: www.jcwhitlam.com

The information contained in this bulletin is correct to the best of our knowledge. The recommendations or suggestions herein are made without guarantee or representation as to result, since the conditions of use are beyond our control. We suggest that you evaluate the recommendations contained in this bulletin. No statement is to be construed as violating any copyright or patent. They are intended only as a source of information.