

WHITLAM

**SAFELY REMOVES
SCALE, LIME
AND RUST**

RECOMMENDED USES:

Scale, lime and rust buildup decreases the efficiency of any water based equipment, increases energy usage, and decreases equipment life.

Flow-Aide® Biodegradable Descaler quickly and safely dissolves water scale, lime, rust, and other water formed deposits, restoring efficiency to most all water based equipment. Flow-Aide® Biodegradable Descaler is a non-toxic concentrate which is certified to NSF/ANSI 60/CAN for use as a cleaner in potable water systems.

COLOR: Amber

TEMPERATURE RANGE USE:

Optimal Operating Temperatures between 65°F (18°C) and 95°F (35°C)

CERTIFICATION

NSF/ANSI 60/CAN 60

AVAILABLE SIZES:

Stock #	Size	Items/Case
FLOW32	1 Quart	12
FLOW1	1 Gallon	6
FLOW5	5 Gallon	1
FLOW55	55 Gallon	1
FLOW275	275 Gallon	1

Certified to NSF/ANSI 60/CAN 60 for use as a cleaner in potable water systems. NSF Registered for use in beverage, pharmaceutical, bottling, poultry, and other food processing plants.

J.C. Whitlam Manufacturing Co.

P.O. Box 380 • Wadsworth, Ohio 44282

U.S. & Canada

Phone: 800-321-8358

Fax: 800-537-0588

International

Phone: 330-334-2524

Fax: 330-334-3005

FLOW-AIDE®

BIODEGRADABLE DESCALER APPLICATION CHART



- **Safe to Handle**
- **Fully Biodegradable***
- **Zero V.O.C.**
- **Non-Toxic**
- **Safe for Potable Water Systems**



FLOW-AIDE®
Dissolving Scale

Descaling Use	Dilution Ratio Water : FLOW	Recommended FLOW-AIDE® and Water Solution	Application Method
Tankless Water Heaters	5:1	1 quart per unit (1-1/4 gals. of water)	Cycle with FLOW-AIDE® Descaler Kit for 30 minutes.
Boilers	Up to 5:1	10 gal. per every 50 gal. Capacity	Feed and soak for 2 hours.
Cooling Tower	2:1	55 gals. per 35 ton	Circulate for 4 hours.
Chillers	4:1	25 gals. per 100 Ton Capacity	Cycle through the system for 3 hours.
Evaporators	5:1	60 gals. per 100 Ton Capacity	Cycle through the system for 3 hours.
Plate Heat Exchangers	2:1	50 gals. per 100 gals.	Soak for 4 hours in a tank.
Secondary Heat Exchanger	5:1	12 ounces per half gallon	Soak in 1 gallon bucket for 2 hours.
Tank Water Heaters	5:1	2 gallons per 40 gallon tank capacity.	Drain tank to 1/4 level. Feed FLOW-AIDE® directly through the drain valve with a hose and funnel. Soak for 1-1/2 hours.
Thermostatic Mixing Valves	5:1	13 ounces per half gallon	Soak in 1 gallon bucket for 1 hour.
Ice Machines	5:1	26 ounces per gallon of water	Cycle or soak parts for 30 minutes.
Coffee Makers	8:1	4 ounces per 32 ounces of water	Cycle though the system.

Distributed By:



WHITLAM

The Industry Standard Over 100 Years

www.flow-aide.com