

TALON LOW VOC CLEAR PRIMER

PLASTIC PIPE PRIMER

PCL-SPEC

PRODUCT DESCRIPTION

PRODUCT

TALON LOW VOC CLEAR PRIMER
Plastic Pipe Primer

TYPE

TALON LOW VOC CLEAR PRIMER is a primer for cleaning, deglazing and softening ABS, PVC and CPVC pipe and fittings prior to application of appropriate cement.

RECOMMENDED USES

TALON LOW VOC CLEAR PRIMER is formulated with a blend of powerful solvents which makes it a fast-acting primer that removes any glaze often found on plastic pipe and fittings and softens the plastic so that it will accept the appropriate plastic solvent cement much more readily.

COLOR/CONSISTENCY

Clear Liquid

TEMPERATURE RANGE USE

0°F (-18°C) to 100°F (38°C)

FOR USE ON:

PVC, ABS and CPVC pipe and fittings.
Up through 16" (40.64 cm) diameter.

WEIGHT PER U.S. GALLON

6.6 lbs. (3.0 kg) ± 0.2

U.S. FEDERAL SPECIFICATIONS

CLEAR PRIMER meets ASTM F656.

Carries the National Sanitation Foundation Seal for Potable Water and Drain, Waste and Vent (DWV) systems.



PCL-SPEC

© 2024 J.C. Whitlam Manufacturing Company
This product is manufactured in the U.S.A.

APPLICATION PRECAUTIONS

WARNING:

EXTREMELY FLAMMABLE.

**DO NOT USE NEAR HEAT,
SPARKS OR OPEN FLAME.**

**STORE IN COOL, WELL
VENTILATED AREA.**

**CONTAINS TETRAHYDROFURAN,
CYCLOHEXANONE, METHYL ETHYL
KETONE AND ACETONE. MAY BE
ABSORBED THROUGH THE SKIN.
HARMFUL OR FATAL IF SWALLOWED.**

**USE WITH ADEQUATE VENTILATION.
AVOID PROLONGED BREATHING OF
VAPORS. AVOID CONTACT WITH
EYES OR SKIN. KEEP CONTAINER
TIGHTLY CAPPED WHEN NOT IN USE.**

KEEP OUT OF REACH OF CHILDREN.

**SEE SAFETY DATA SHEET (SDS) FOR
COMPLETE PRECAUTIONS FOR SAFE
HANDLING AND USE.**

PACKAGING

U.S. Measure:

<u>Stock Code</u>	<u>Size</u>
Dauber Top Can	
PCL8	½ pint (237 ml)
PCL16	1 pint (473 ml)
PCL32	1 quart (.95 L)
1 Gallon Can w/ Handle	
PCL1	Gallon (3.785 L)

SHIPPING WEIGHT PER CASE

<u>Stock Code</u>	<u>Case Weight</u>	<u>#/Case</u>
PCL8	15 lbs. (6.8 kg)	24
PCL16	14 lbs. (6.4 kg)	12
PCL32	26 lbs. (11.8 kg)	12
PCL1	50 lbs. (22.7 kg)	6

DIRECTIONS FOR USE

1. Check the fitting of pipe. If it is too loose or too tight, the pipe should not be used. The ideal fit between pipe and fitting before cleaning and cementing allows pipe to enter to full depth of socket easily.

2. Remove all dust, moisture, grease, oil and any foreign material from pipe and fitting.

3. Apply generous amounts of **TALON LOW VOC CLEAR PRIMER** to pipe and fitting. If the surface is dry when ready to apply cement, apply additional **TALON LOW VOC CLEAR PRIMER** so that cement is applied to a damp surface.

4. Keep container closed at all times when not using to avoid moisture absorption and vapor losses.

5. Follow all recommended procedures for joining plastic pipe and fittings as stated in ASTM D2855, D2235 and/or F493 where applicable.

6. **DO NOT USE THIS LOW VOC CLEAR PRIMER TO THIN CEMENT.**



P.O. Box 380 • Wadsworth, OH 44282 U.S.A.
Phone: 1-330-334-2524 • FAX 1-330-334-3005
Email: info@jcwhitlam.com
Website: www.joinpipe.com